



TYLKO DLA INFORMACJI
 Po zamontowaniu drzwi przesuwanych po zmianach, konieczne jest sprawdzenie wymiarów kieszeni na wr 13.3, zapewniających brak kolizji ze skrzydłem drzwi.

- UWAGI**
- Kątowniki i płyty 2 mm każdej kieszeni giąć w 1 płaszczyźnie. Osie gięcia równoległe do PS okrętu.
 - Spawanie wszystkich elementów do kadłuba okrętu wykonać spoiną 3.5
 - Ostre krawędzie zaokrąglić.
 - Malowanie wg ustalenia z Muzeum MW

Rev.	Date	Name	Revision subject

		Date:	Name:
		Designed by:	T. Dusza
ul. Marynarki Polskiej 163, 80-868 Gdansk, Poland www.nava.com.pl		Checked by:	T. Dusza
		Issued by:	R. Dunajski

KIESZEŃ RUFOWYCH DRZWI PRZESUWANYCH		QC-22501 KOB BEN	
		294-QC-22501-200	
Scale:	Format:	Sheet:	Sheets:
1:20	A1	1	1

NAVA hereby claims all copyrights and intellectual property rights to the above technical drawing to belong exclusively to NAVA unless stated otherwise. Neither this technical drawing nor any part of it can be used in any way without the consent of NAVA. Copying, publishing in any way, modification or other use, including for commercial purposes, is prohibited.