


8.6. Accessories and spare parts list

Description	Code
FAN MODULE COOL UNIT V4	E,0018233
EXCHANGEABLE FILTER COOL UNIT V4	E,0018252
TEMPERATURE SENSOR COOL UNIT V4	E,0018253
HUMIDITY SENSOR COOL UNIT V4	E,0018254
WATER LEAK SENSOR COOL UNIT V4	E,0018255
CONDENSATION PUMP (20M) COOL UNIT V4	E,0018256
OPEN DOOR (x4) DETECTOR KIT COOL UNIT V4	E,0018257
OPEN DOOR (x6) DETECTOR KIT COOL UNIT V4	E,0018258
SMOKE DETECTOR COOL UNIT V4	E,0018259
VISUAL ALARM WITH SOUND COOL UNIT V4	E,0018260
VISUAL ALARM WITHOUT SOUND COOL UNIT V4	E,0018261
SUBC. 3 WAY VALVE COOL UNIT V4	I,0018229.329
SUBC. FLOWMETER COOL UNIT V4	I,0018229.330
SUBC. POWER SUPPLY COOL UNIT V4	I,0018229.312

To place an order, please contact your usual Saifor products supplier.

13. Internal water circuit diagram



— Rigid pipe
 Flexible pipe

- 1 Coil
- 2 Air bleed
- 3 Water outlet pipe
- 4 Water inlet pipe
- 5 3-way modulating valve
- 6 Flow meter
- 7 Condensate pump
- 8 Tank+ level sensor
- 9 Drain valve
- 10 Condensate tray